

Up-grade set for MINICAT 460



Installation procedure



1 Attach the shackle on the right and left sides of the front frame.



2 When assembling the boat, attach the wires with the straining devices as shown on the photo.



4 When the boat is assembled, tighten the straining devices so that the wires are strongly stretched.